

NOTE 1

If step 1 (TRAY 1) still results in no knob B activity:

Place thumb of one hand on number display of knob

Hold thumb in place and grasp knob with other hand

Push on number display with thumb, while carefully pulling and gently twisting gold cover off to reveal black knob underneath

Retry step 1 (TRAY 1), turning black knob with USUAL force

If successful, complete knob B steps (TRAY 1), and then replace gold cover

If knob still does not turn, replace gold knob cover and go to step 4 (TRAY 1)

NOTE 2

Proceed until number display of knob reads 200 or the number stops increasing

FEED #6							
OSTEO TRAY		Knob A (BLUE)	Knob B (GOLD)	Knob C (SILVER)	Knob D (RED)	Comments	
<div>1</div> <div>MET ____/____:</div> <div>Knob Settings</div>	1		M1, 120			See NOTE 1 (top of pg)	
	2		M2, 240				
	3		M3, 360				
	4	M1, 121					
	5	M3, 164					
	6	M2, 200					See NOTE 2 (top of pg)
<div>2</div> <div>MET ____/____:</div> <div>Knob Settings</div>	1		F, 801				
	2		M1, 920				
	3		M2, 039				
	4		M3, 158				
	5						
	6						
<div>3</div> <div>Knob Settings</div>	1	N/A	N/A	N/A	N/A		
	2	N/A	N/A	N/A	N/A		
	3	N/A	N/A	N/A	N/A		
	4	N/A	N/A	N/A	N/A		
	5	N/A	N/A	N/A	N/A		
	6	N/A	N/A	N/A	N/A		
<div>4</div> <div>Knob Settings</div>	1	N/A	N/A	N/A	N/A		
	2	N/A	N/A	N/A	N/A		
	3	N/A	N/A	N/A	N/A		
	4	N/A	N/A	N/A	N/A		
	5	N/A	N/A	N/A	N/A		
	6	N/A	N/A	N/A	N/A		

- MF71G
- Record knob settings in table above
 - Close and secure Middeck locker door
 - Notify MCC (current knob settings, METs, and comments) within 15 min to facilitate ground experiments